

Documenting the Airvo 2 or other high flow O2 device asset numbers

Quick reference guide

The machine identifier number (QH asset number) should be documented at the commencement of therapy or if a new device is used to deliver therapy.

1. In the patient's record navigate to [Interactive View](#)
2. In the [Paediatric Systems Assessment](#) navigator band go to [Respiratory](#)
3. Record the device asset number in the [Respiratory machine identifier](#) box. This can be completed by scanning the QH asset number label with the barcode scanner attached to the point of care terminal. Note this is not the manufacturer's serial number.

Respiratory	
Oxygen flow rate	L/min
FIO2	%
High flow rate	L/min
Humidifier temperature	deg C
Humidifier safety check	
Respiratory machine identifier	
Sputum amount	

4. Right click on the [Respiratory machine identifier](#) box and select [Flag](#). This will display the documentation on the [Patient Summary Page](#) for easy review during handover.
5. [Sign](#) the documentation by selecting the green tick.



Paediatric Quick View	
<input checked="" type="checkbox"/>	Paediatric Systems Assessment
<input type="checkbox"/>	Vital Signs
<input type="checkbox"/>	Pain Assessment Paediatric
<input type="checkbox"/>	Pain Re-Evaluation
<input checked="" type="checkbox"/>	Respiratory

Flagged Events (1)	
Selected Visit: Last 30 days	
Event/Comment	Date
Respiratory machine 123 identifier	30/04/20 13:43

Note: If you require any additional assistance please contact the Health Informatics Team on 3068 1999

